

MONTIS CZ s.r.o.

Moravská 2715/61, 767 01 Kroměříž

IČ 25583395 montis@montis.cz www.montis.cz

INSTRUCTIONS FOR USE, MAINTENANCE AND WARRANTY TERMS**BEACH FAGS**

1. Product Description

Advertising flag systems designed for short- to medium-term outdoor use.

2. Operating Instructions

Assembly: Assemble the frame, slide the textile sleeve onto the pole and secure it with the cord to the eyelet on the frame. Tension by pulling, then insert the lower part of the frame onto or into the base (cross base, ground spike, or weighted base).

Stability: Ensure proper ballasting/weighting of the flag at all times.

3. Maintenance**Fabric care:**

- The cover is made of 100% polyester fabric. Clean soiled areas with lukewarm water (max. 60 °C) using a mild soap or detergent-based cleaner.
- Do not use bleaching agents or fabric softeners.
- Dirt can be removed with a foam sponge or a soft cloth.
- After cleaning, rinse the cover with clean water and allow it to dry completely. During drying, do not expose the product to direct radiant heat.

Frame care:

- Keep the frame clean by gently wiping it with a cloth and a mild soapy solution.
- Wash the textile by hand in cold water only.
- Do not store while wet.

Storage:

- Before long-term storage, clean the flag and allow it to dry completely.
- Store in a dry place.

3. Material, Finishing and Graphic Processing

- **Fabrics and water resistance:**

The fabrics used are factory-treated with an impregnation to increase water repellency. However, these materials are not 100% waterproof.

- **Selection of materials and colours:**

If the customer does not explicitly specify colour, type, or finishing details in the order, the manufacturer reserves the right to select a suitable option based on current material availability and technological possibilities.

- **Graphic designs and seam alignment:**

For printed products, please note that complex or extensive graphics may not always align precisely across stitched parts and may partially extend into seams or overlaps. If exact graphic alignment or placement outside seams is required, we recommend preparing a graphic proof in advance or, for larger volumes, producing a sample, or consulting this requirement beforehand with a sales representative or production.

5. Warranty Conditions**5.1 Warranty period**

- Frame: 24 months
- Textile cover and print: 12 months

The warranty period starts from the date the product is received.

5.2 Scope of warranty

The warranty covers manufacturing defects in materials and workmanship that prevent normal use of the product. MONTIS CZ s.r.o., depending on the nature of the defect, will arrange repair, replacement, or an appropriate price reduction. The method of settlement is determined by the manufacturer.

5.3 Warranty exclusions

The warranty **does not** cover:

- damage caused by incorrect assembly, handling, or transportation
- use in unsuitable weather conditions
- use of non-original parts, bases, or anchoring systems
- normal wear and tear of materials and colour changes caused by UV radiation
- cracks, tears, or damage caused by mechanical stress
- moisture, mould, rust, oils, chemicals, or improper cleaning
- intentional damage, third-party interference, and force majeure events (storms, wind, fire, flooding)

Normal fading of the print and **slight colour changes after 6 months** of outdoor exposure are considered a natural effect of UV exposure and **do not constitute a defect**.

7. Service and Spare Parts

MONTIS CZ s.r.o. ensures the availability of spare parts and service support during and after the warranty period. If repair is not feasible, the manufacturer may offer an equivalent replacement or an appropriate discount.

8. Final Provisions

These warranty conditions and operating instructions are valid from 1 January 2025 and replace all previous versions. All legal relationships are governed by Act No. 89/2012 Coll., the Civil Code. Statutory rights of the buyer remain unaffected by the application of this warranty.

Contact for complaints and service:

MONTIS CZ s.r.o.

Moravská 2715/61, 767 01 Kroměříž, Czech Republic

montis@montis.cz www.montis.cz

Installation Instructions



Nachystejte stojan dle druhu podloží a zajistěte svislou polohu



Zkontrolujte obsah balení



Spojte hliníkové trubky včetně oblouku na dorazy



Opatrně navlékejte vlajku na konstrukci



Vložte konstrukci do stojanu



Vlajku postupně vypínajte



Zajistěte lanko uzlem v kroužku



Umožněte otáčení vlajky